SEAT

Engine type	Engine	Year of manufacture	Engine type									Transmission															Steering booster					Cooling system				
												Gear box											Differential													
												Manual transmission						Automatic transmission																			
			Filling capacity, L	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 504/507	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 75W-80 GL 4	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Note	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Red 12+	XADO Antifreeze Green 11	XADO Antifreeze Blue BS
Seat - Alhambra																																				
Alhambra 1.8 20VT	AJH	1997-00	4,5	○	○			●	●			2,2			●			6		●			0,8	●		a	0,9			●		7/9/9,6		●		
Alhambra 1.8 20VT	AJH	2000-	4,5	○	○			●	●			2,5		●				7		●										●		7/9/9,6		●		
Alhambra 2.0	ADY	1996-00	4	○	○			●	●			2,2			●			6		●			0,8	●		a	0,9			●		7/9/9,6		●		
Alhambra 2.0	ADY	2000-	4,5	○	○			●	●			2,5		●				6		●			0,8	●		a				●		7/9/9,6		●		
Alhambra 2.8 V6	AYL	2000-	5,5	○	○			●	●			2,5		●				7		●										●		9/10,8/11,4		●		
Alhambra 2.8 V6 4x4	AYL	2001-05	5,5	○	○			●	●			2,8		●									1	●		b				●		9/10,8/11,4		●		
Alhambra 1.9 TDi (66 kW)	1Z, AHU	1996-00	4,3		○			●	●			2,2			●												0,9			●		6,8/8,6/9,2		●		
Alhambra 1.9 TDi (66 kW)	ANU (PD)	2000-03	5,5			○	●					2,5		●																●		6,8/8,6/9,2		●		
Alhambra 1.9 TDi (81 kW)	AFN	1996-00	4,3		○			●	●			2,2			●			6		●			0,8	●		a	0,9			●		6,8/8,6/9,2		●		
Alhambra 1.9 TDi (85 kW)	AUY (PD)	2000-07	4,3			○	●					2,5		●				7		●										●		6,8/8,6/9,2		●		
Alhambra 1.9 TDi (85 kW) 4x4	AUY (PD)	2000-05	4,3			○	●					2,8		●									1	●		b				●		6,8/8,6/9,2		●		
Alhambra 1.9 TDi (96 kW)	ASZ (PD)	2003-05	4,3			○	●					2,5		●																●		6,8/8,6/9,2		●		
Alhambra 2.0 TDi (103 kW)	BKD (PD)	2005-	3,8			○	●					2,5		●																●				●		

Notes:

a -front differential (automatic transmission);

b -rear differential.

Engine type	Engine	Year of manufacture	Engine type									Transmission															Steering booster					Cooling system				
												Gear box											Differential													
												Manual transmission						Automatic transmission																			
			Filling capacity, L	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 504/507	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 75W-80 GL 4	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Note	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Red 12+	XADO Antifreeze Green 11	XADO Antifreeze Blue BS
Seat - Altea																																				
Altea 1.4 16V		2006-	3,2		○	●	●	○	○			2		●																		5,6	●	●		
Altea 1.4 TSI	CAXC	2007-	3,6		○	●	●	○	○			2		●																			●	●		
Altea 1.6		2004-	4,5		○	●	●	○	○			2		●																			●	●		
Altea 1.8 TSI	BYT, BZB	2006-	4,6		○	●	●	○	○			2,1		●																			●	●		
Altea 2.0 FSI		2005-	4,6		○	●	●	○	○			2,1		●				5,9	●	○												8	●	●		
Altea 2.0 TFSI		2006-	4,6		○	●	●	○	○			2,3		●				7				a											●	●		
Altea 1.9 TDi	BJB, BKC (PD)	2004-	4,3			●	●					2		●																			●	●		
Altea 1.9 TDi DPF	BLS (PD)	2006-	4,3			●	●					2		●																			●	●		
Altea 2.0 TDi (103 kW)	BKD (PD)	2004-	3,8			●	●					2,3		●				7,2				a											●	●		
Altea 2.0 TDi (103 kW) DPF	BMM (PD)	2006-	4,3			●	●					2,3		●				7,2				a											●	●		
Altea 2.0 TDi (125 kW) DPF	BMN (PD)	2006-	3,8			●	●					2,3		●																		8	●	●		

Notes:

a - ATF DSG.

Engine type	Engine	Year of manufacture	Engine type									Transmission														Steering booster					Cooling system				
												Gear box											Differential													
												Manual transmission						Automatic transmission																		
			Filling capacity, L	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 504/507	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 75W-80 GL 4	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Note	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Red 12+	XADO Antifreeze Green 11	XADO Antifreeze Blue BS
Seat - Altea Free Track																																			
Altea Free Track 2.0 TSI 4WD	BWA	2007-	4,6			●						2,3		●									1	●		a						●	●		
Altea Free Track 2.0 TDI (103 kW) 2WD	BKD (PD)	2007-	3,8			●	●					2,3		●																		●	●		
Altea Free Track 2.0 TDI (103 kW) 4WD	BKD (PD)	2008-	3,8			●	●					2,3		●									1	●		a						●	●		
Altea Free Track 2.0 TDI (125 kW) 4WD	BMN (PD)	2007-	3,8			●	●					2,3		●									1	●		a						●	●		

Notes:

a -rear differential.

Seat - Altea XL																																			
Altea XL 1.4 16V		2006-	3,2	○		●	○					2		●																	5,6	●	●		
Altea XL 1.4 16V	CAXC	2007-	3,6	○		●	○					2		●																		●	●		
Altea XL 1.6	BSE	2006-	4,5	○		●	○					2		●																		●	●		
Altea XL 1.8 TSI	BYT, BZB	2006-	4,6	○		●	○					2,1		●																		●	●		
Altea XL 2.0 FSi	BVY	2006-	4,6	○		●	○					2,1		●																		●	●		
Altea XL 1.9 TDi DPF	BXE (PD)	2006-	4,3			●	●					2		●																		●	●		
Altea XL 2.0 TDi (103 kW) DPF	BKD, BMM (PD)	2006-	4,3			●	●					2,3		●				7,2				a										●	●		
Altea XL 2.0 TDi (125 kW) DPF	BMN (PD)	2007-	3,8			●	●					2,3		●																	8	●	●		

Notes:

a - ATF DSG.

Seat - Arosa																																			
Arosa 1.0	AER	1997-05	3,4	○	○			●	●			2,7	●																		5,6		●		
Arosa 1.4	AEX	1997-05	3,4	○	○			●	●			2,7	●							●				●		a					5,6		●		
Arosa 1.4 16V		1997-05	3,4	○	○			●	●			2,7	●																		5,6		●		
Arosa 1.4 TDi	AMF (PD)	1999-05	4,2			○	●					2,7	●																		5		●		
Arosa 1.7 SDi	AKU	1997-05	3,4		○	○	●					2,7	●																		6,5		●		

Notes:

a - front differential (automatic transmission).

Seat - Cordoba																																			
Cordoba 1.0	ALD, ANV	1999-03	3,2	○	○			●	●			2,7	●														0,9			●		5,6		●	○	
Cordoba 1.2 12V	AZQ	2003-06	3	○	●		●	○	○			2,1		●																		5,6		●		
Cordoba 1.2 12V	BXV	2006-08	3	○	●	●	●					2,1		●																●		5,6		●		
Cordoba 1.4	ABD	1993-99	3,5	○	○			●	●			2	●														0,9			●		6,6		●	○	
Cordoba 1.4	ANW, AKK	1999-03	3,2	○	○			●	●			2,7	●														0,9			●		5,6		●	○	

Engine type	Engine	Year of manufacture	Engine type									Transmission														Steering booster					Cooling system				
												Gear box										Differential													
												Manual transmission						Automatic transmission																	
			Filling capacity, L	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 504/507	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 75W-80 GL 4	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Note	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Red 12+	XADO Antifreeze Green 11	XADO Antifreeze Blue BS
Cordoba 1.4 16V (55 kW)		2003-08	3,2	○	●		●	○	○			2,1		●				5,7		●							5,6					5,6		●		
Cordoba 1.4 16V (63 kW)	BXW	2006-09	3,2	○	●	●	●					2,1		●																●		5,6		●		
Cordoba 1.4 16V (74 kW)	AFH	1997-99	3,5	○	○			●	●			2	●										0,9							●		6,6		●	○	
Cordoba 1.4 16V (74 kW)	ANW, AKK	1999-03	3,2	○	○			●	●			2,7	●										0,9							●		5,6		●	○	
Cordoba 1.4 16V (74 kW)		2003-07	3,2	○	●		●	○	○			2,1		●																		5,6		●		
Cordoba 1.6 (55 kW)	ABU	1993-99	4	○	○			●	●			2	●										0,9							●		6,6		●	○	
Cordoba 1.6 (55 kW)	ALM	1999-03	3,4	○	○			●	●			2,7	●										0,9							●		5,5		●	○	
Cordoba 1.6 (74 kW)	AFT	1996-99	4	○	○			●	●			2	●										0,9							●		6,6		●	○	
Cordoba 1.6 (74 kW)	AEH, AKL	1999-03	4,5	○	○			●	●			1,9	●					3		●			0,75	●		a	0,9			●		5,5		●	○	
Cordoba 1.6 (74 kW)	BAH	2003-07	4	○	●		●	○	○			2,1		●																		5		●		
Cordoba 1.6 16V	BTS	2007-08	3,6	○	●	●	●					2,1		●																				●		
Cordoba 1.8	ABS, ADZ	1993-97	4					●	●	○	○	2	●					3			●		0,75	●		a	0,9			●		6,6		●	○	
Cordoba 1.8 16V	ADL	1993-97	4					●	●	○	○	2	●														0,9			●		6,6		●	○	
Cordoba 1.8 20VT	AYP	1999-03	5,3	○	○			●	●			1,9	●														0,9			●		6,5		●	○	
Cordoba 2.0	AGG	1993-99	4	○	○			●	●			2	●														0,9			●		6,6		●	○	
Cordoba 2.0		2003-05	4	○	●		●	○	○			2,1		●																		5		●		
Cordoba 2.0 16V	ABF	1996-99	4	○	○			●	●			2	●														0,9			●		6,6		●	○	
Cordoba 1.4 TDi (51 kW)	BNM	2005-08	3,8			●	●					1,9		●																●		5,5		●		
Cordoba 1.4 TDi (55 kW)	AMF (PD)	2003-05	4,2			●	●					1,9		●																		5		●		
Cordoba 1.4 TDi (58 kW)	BNV	2007-08	3,8			●						1,9		●																●		5,5		●		
Cordoba 1.4 TDi (59 kW)	BMS	2007-09	3,8			●						2		●																●				●		
Cordoba 1.9 D	1Y	1993-99	4,5	○	○	●		○	○			2	●										0,9							●		6,6		●	○	
Cordoba 1.9 SDi	AEY	1996-99	4,5	○	○	●		○	○			2	●										0,9							●		6,6		●	○	
Cordoba 1.9 SDi	AGP, AQM	1999-03	4,5		○	●	●	○	○			2	●										0,9							●		6		●	○	
Cordoba 1.9 SDi	ASY	2003-06	4,3		○	●	●	○	○			2		●																		6		●		
Cordoba 1.9 TD	AAZ	1993-97	4,5		○			●	●			2	●										0,9							●		6,6		●	○	
Cordoba 1.9 TDi (66 kW)	1Z	1996-99	4,5		○			●	●			2	●										0,9							●		6,5		●	○	
Cordoba 1.9 TDi (66 kW)	AGR, ALH	1999-03	4,5		○	●	●	○	○			2	●										0,9							●		6		●	○	
Cordoba 1.9 TDi (74 kW)	ATD (PD)	2003-08	4,5			●	●					1,9		●																		5		●		
Cordoba 1.9 TDi (81 kW)	AFN	1998-03	4,5		○	●	●	○	○			2	●										0,9							●		6,5		●	○	
Cordoba 1.9 TDi (96 kW)	ASZ (PD)	2003-06	4,5			●	●					2,3		●																		5		●		

Notes:

a - front differential (automatic transmission).

Engine type	Engine	Year of manufacture	Engine type									Transmission														Steering booster					Cooling system				
												Gear box											Differential													
												Manual transmission						Automatic transmission																			
			Filling capacity, L	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 504/507	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 75W-80 GL 4	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Note	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Red 12+	XADO Antifreeze Green 11	XADO Antifreeze Blue BS
Seat - Exeo																																			
Exeo 1.6	ALZ	2009-	3,8			●	○					3	●																	●					●	●		
Exeo 1.8 T	CFMA	2009-	4,5			●	○					3	●																	●					●	●		
Exeo 2.0 TSI	BWE	2009-	4,6			●	○					3	●																	●					●	●		
Exeo 2.0 TDI (105 kW)	CAGA	2009-	4,3			●						3	●																	●					●	●		
Exeo 2.0 TDI (125 kW)	CAHA	2009-	4,3			●						3	●																	●					●	●		
Seat - Ibiza																																			
Ibiza 1.0	AER	1997-99	3,5	○	○			●	●			3,1	●														0,9			●		6,6		●	○	
Ibiza 1.0	ALD, ANV	1999-02	3,5	○	○			●	●			2,7	●														0,9			●		5,5		●	○	
Ibiza 1.05	AAU	1993-96	4					●	●	○	○	3,1	●														0,9			●		4,2		●	○	
Ibiza 1.2	BME	2002-06	3		●	●	●	○	○			1,9		●																●		5,6		●		
Ibiza 1.2 12V	AZQ	2002-06	3		●	●	●	○	○			1,9		●																●		5,6		●		
Ibiza 1.2 12V	BXV	2006-08	3		●	●	●	○	○			2,1		●																●		5,6		●		
Ibiza 1.2 12V	BZG	2008-	2,8		○	●	●					2		●																●			●	●		
Ibiza 1.4	ABD	1994-99	3,5	○	○			●	●			3,1	●														0,9			●		4,2		●	○	
Ibiza 1.4	ANW, AKK	1999-02	3,2	○	○			●	●			2,7	●														0,9			●		4,2		●	○	
Ibiza 1.4 16V	AFH	1997-99	3,5	○	○			●	●			2,7	●														0,9			●		6,6		●	○	
Ibiza 1.4 16V	AFH	1999-02	3,5	○	○			●	●			2,7	●														0,9			●		5,5		●	○	
Ibiza 1.4 16V (55 kW)	FDM	2002-08	3,2		●	●	●	○	○			2,1		●				5,7		●										●		6		●		
Ibiza 1.4 16V (63 kW)	BXW	2006-	3,2		●	●	●	○	○			2,1		●																●		5,6	●	●		
Ibiza 1.4 16V (74 kW)	AUB	2002-07	3,2		●	●	●	○	○			2,1		●																●		6		●		
Ibiza 1.6 (55 kW)	ABU	1993-99	3,5	○	○			●	●			2/3,1	●					3		●			0,75	●		a	0,9			●		5,5		●	○	
Ibiza 1.6 (55 kW)	ALM	1999-02	3,4	○	○			●	●			2,7	●														0,9			●		5,5		●	○	
Ibiza 1.6 (74 kW)	AFT	1996-99	3,5	○	○			●	●			2	●														0,9			●		5,5		●	○	
Ibiza 1.6 (74 kW)	AEH, AKL	1999-02	4,5	○	○			●	●			1,9	●					3		●			0,75	●		a	0,9			●		5,5		●	○	
Ibiza 1.6 16V (77 kW)	BTS	2007-	3,6		○	●	●					2,1		●																●			●	●		
Ibiza 1.8	ABS, ADZ, ACC	1993-97	4					●	●	○	○	2	●					3			●		0,75	●		a	0,9			●		5,5		●	○	
Ibiza 1.8 16V	ADL	1993-97	4					●	●	○	○	2	●														0,9			●		6,6		●	○	
Ibiza 1.8 20VT		1999-02		○	○			●	●			2	●														0,9			●				●	○	
Ibiza 1.8 20VT		2004-08	4,5		●	●	●	○	○			2		●													0,9			●		5		●		
Ibiza 1.8 20VT Cupra R		2005-08	4,5		●	●	●	○	○			2		●													0,9			●		5		●		
Ibiza 2.0	AGG	1993-99	4	○	○			●	●			2	●														0,9			●		6,6		●	○	
Ibiza 2.0	AZL	2003-05	4		●	●	●	○	○			2,1		●																●		5		●		
Ibiza 2.0	CEKA	2008-	4		○	●	●					2		●																●			●	●		
Ibiza 2.0 16V	ABF	1996-99	4	○	○			●	●			2	●														0,9			●		5,5		●	○	
Ibiza 1.4 TDi (51 kW)	BNM	2005-08	3,8		○	●	●					1,9		●																●		5,5		●		

Engine type	Engine	Year of manufacture	Engine type									Transmission													Steering booster					Cooling system				
												Gear box										Differential														
												Manual transmission						Automatic transmission																		
			Filling capacity, L	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 504/507	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 75W-80 GL 4	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Note	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Red 12+	XADO Antifreeze Green 11	XADO Antifreeze Blue BS
Ibiza 1.4 TDi (55 kW)	AMF (PD)	2002-05	3,8				●					1,9		●																●		5,5		●		
Ibiza 1.4 TDi (58 kW)	BNV	2007-08	3,8			●						1,9		●																●		5,5		●		
Ibiza 1.4 TDi (59 kW)	BMS	2007-	4,4			●						2		●																●			●	●		
Ibiza 1.9 D	1Y	1993-99	4,5		○			●	●			2	●														0,9			●		6,6		●	○	
Ibiza 1.9 TD	AAZ	1993-97	4,5		○			●	●			2	●														0,9			●		6,6		●	○	
Ibiza 1.9 SDi	AEY	1996-99	4,5		○			●	●			2	●														0,9			●		6,6		●	○	
Ibiza 1.9 SDi	AGP, AQM	1999-02	4,5		○			●	●			1,9	●														0,9			●		6,6		●	○	
Ibiza 1.9 SDi	ASY	2002-05	4,3		○	●	●					1,9	●																	●		5		●		
Ibiza 1.9 TDi (66 kW)	1Z	1996-99	4,5		○			●	●			2	●														0,9			●		6,6		●	○	
Ibiza 1.9 TDi (66 kW)	AGR, ALH	1999-02	4,5		○			●	●			2	●														0,9			●		6,6		●	○	
Ibiza 1.9 TDi (66 kW)	BXJ	2008-	4,5			●						2		●																●			●	●		
Ibiza 1.9 TDi (74 kW)	ATD (PD)	2002-08	4,5				●					1,9		●																●		5		●		
Ibiza 1.9 TDi (77 kW)	BLS (PD)	2008-	4,5			●	●					1,9		●																●		5	●	●		
Ibiza 1.9 TDi (77 kW)	AFN	1997-02	4,5		○			●	●			2	●														0,9			●		6,6		●	○	
Ibiza 1.9 TDi (96 kW)	ASZ (PD)	2002-08	4,5				●					2,3		●																●		5		●		
Ibiza 1.9 TDi (118 kW)	BPX, BUK (PD)	2004-08	4,5				●					2,3		●																●		5		●		

Notes:

a - front differential (automatic transmission).

Engine type	Engine	Year of manufacture	Engine type									Transmission													Steering booster					Cooling system				
												Gear box										Differential														
												Manual transmission						Automatic transmission																		
			Filling capacity, L	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 504/507	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 75W-80 GL 4	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Note	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Red 12+	XADO Antifreeze Green 11	XADO Antifreeze Blue BS
Seat - León																																		
León 1.4 16V	AHW	1999-05	3,2	○	●	●	●	○				1,9	●																		5		●		
León 1.4 16V		2006-	3,2	○	●	●	●					2		●																	5,6	●	●		
León 1.4 TSI	CAXC	2008-	3,6	○	●	●	●					2		●																		●	●		
León 1.6	AEH, AKL	1999-01	4,5	○	●	●	●	○				1,9	●																		5		●		
León 1.6		2005-	4,5	○	●	●	●	○				2		●																		●	●		
León 1.6 16V	BCB	2001-06	4,5	○	●	●	●	○				2	●					3		●			0,75	●		b				●	5		●		
León 1.8 20V	AGN	1999-05	4,5	○	●	●	●	○				2	●					3		●			0,75	●		b	0,9			●	5		●		
León 1.8 20VT	APP	1999-05	4,5	○	●	●	●	○				2,4	●														0,9			●	5		●		
León 1.8 20VT 4	APP	2001-03	4,5	○	●	●	●	○				2,6	●										1	●		c	0,9			●	5		●		
León 1.8 20VT Cupra R	AMK	2002-05	4,5	○	●	●	●	○				2,4		●																●	5		●		
León 1.8 TSI	BYT, BZB	2007-	4,6	○	●	●	●					2,1		●																		●	●		
León 2.0 FSI		2005-	4,6	○	●	●	●	○				2		●				7	●	○												●	●		
León 2.0 TFSI	BWA	2005-06	4,6	○	●	●	●	○				2,3		●				5,9	●	○													●		
León 2.0 TFSI FR	BWA	2006-	4,6	○	●	●	●					2,3		●				7				a									8	●	●		
León 2.0 TFSI Cupra	BWA	2006-		○	●	●	●					2,3		●																		●	●		
León 2.8 V6 Cupra 4	AUE	2001-04	5,5	○	●	●	●	○				2,6		●									1	●		c				●	9,2		●		
León 1.9 SDi	AGP, AQM	2000-04	4,5		○	●	●	○				1,9	●														0,9			●	6		●		
León 1.9 TDi (66 kW)	AGR, ALH	1999-05	4,5		○	●	●	○				2	●														0,9			●	6		●		
León 1.9 TDi (74 kW)	AXR (PD)	2006	4,3				●					2	●														0,9			●	5	●	●		
León 1.9 TDI (77 kW)	BKC (PD)	2005-	4,3				●					2		●																		●	●		
León 1.9 TDI (77 kW) DPF	BLS (PD)	2006-	4,3			●	●					2		●				7,2				a										●	●		
León 1.9 TDi (81 kW)	AHF, ASV	2000-05	4,5		○	●	●	○				2	●														0,9			●	6		●		
León 1.9 TDi (96 kW)	ASZ (PD)	2004-05	4,3				●					2,4		●																●	5		●		
León 1.9 TDi (110 kW)	ARL (PD)	2001-06	4,5				●					2,4		●																●	6		●		
León 1.9 TDi (110 kW) 4	ARL (PD)	2001-04	4,5				●					2,6		●									1	●		c				●	6		●		
León 2.0 TDi (103 kW)	BKD (PD)	2005-	3,8				●					2,3		●				7,2				a										●	●		
León 2.0 TDi (103 kW) DPF	BMM (PD)	2006-	4,3			●	●					2,3		●				7				a										●	●		
León 2.0 TDi (125 kW) DPF	BMN (PD)	2006-	3,8			●	●					2,3		●																	8	●	●		

Notes:

a - see the Operation manual;

b - front differential (automatic transmission).

c - rear differential.

Engine type	Engine	Year of manufacture	Engine type									Transmission														Steering booster					Cooling system				
												Gear box										Differential														
												Manual transmission						Automatic transmission																		
			Filling capacity, L	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 504/507	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 75W-80 GL 4	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Note	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Red 12+	XADO Antifreeze Green 11	XADO Antifreeze Blue BS
Seat - Marbella																																				
MARBELLA 0.8, 0.9		1987-98	3,6					●	●	○	○	2,4	●																		5,2			●	○
Seat - Toledo																																				
Toledo 1.4 16V	AHW	2000-01	3,2	○		○		●	●			1,9	●																●		6		●		
Toledo 1.6		1992-98	4					●	●	○	○	2	●	○												0,6			●		7			●	
Toledo 1.6	AEH, AKL	1998-04	4,5	○		○		●	●			1,9	●					3		●			0,75	●		a				●		5		●		
Toledo 1.6		2004-	4,5	○	●	●	●	○	○			2		●																				●		
Toledo 1.8		1992-98	4					●	●	○	○	2	●	○												0,6			●		7			●	
Toledo 1.8 GT 16V		1992-94	4					●	●	○	○	2	●	○												0,6			●		7			●	
Toledo 1.8 20V	AGN	1998-04	4,5	○		○		●	●			2	●					3		●			0,75	●		a				●		5		●		
Toledo 1.8 TSI	BYT, BZB	2007-	4,6	○	●	●	●	○	○			2,1		●																				●		
Toledo 2.0		1992-98	4					●	●	○	○	2	●	○				3		●			0,75	●		a	0,6			●		7			●	
Toledo 2.0 16V		1995-98	4					●	●	○	○	2	●	○												0,6			●		6,2			●	
Toledo 2.0 FSI		2004-	4,6	○	●	●	●	○	○			2		●				5,9	●	○														●		
Toledo 2.3 V5	AGZ	1998-04	4	○		○		●	●			1,9	●																●		9		●		
Toledo 1.9 D		1992-98	4,5			○		●	●			2	●	○												0,6			●		6,2			●	
Toledo 1.9 TD		1992-98	4,5			○		●	●			2	●	○												0,6			●		6,2			●	
Toledo 1.9 TDi (66 kW)	1Z	1996-98	4,5			○		●	●			2	●													0,6			●		6,2			●	
Toledo 1.9 TDi (66 kW)	AGR, ALH	1998-04	4,5			○		●	●			2	●																●		6		●		
Toledo 1.9 TDi (81 kW)	AHF, ASV	1998-04	4,5			○		●	●			2	●																●		6		●		
Toledo 1.9 TDi (96 kW)	ASZ (PD)	2003-04	4,5				●					2,4		●															●		5		●		
Toledo 1.9 TDi (110 kW)	ARL (PD)	2001-04	4,5				●					2,4		●															●		6		●		
Toledo 1.9 TDi	BJB, BKC (PD)	2004-	4,3			●	●					2		●																			●		
Toledo 1.9 TDi DPF	BLS (PD)	2006-	4,3		●							2		●																			●		
Toledo 2.0 TDi	BKD (PD)	2004-	3,8			●	●					2,3		●				7,2				b											●		
Toledo 2.0 TDi DPF	BMM (PD)	2006-	4,3		●							2,3		●																			●		

Notes:

a - front differential (automatic transmission).

b - see the Operation manual.