FORD

Engine type	Engine	Year of manufacture	Engine type														Transmission																	Steering booster				Cooling system		
																	Gear box												Differential												
																	Manual transmission							Automatic transmission																
			Filling capacity, L	XADO 0W-30 SL/CF	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 A5/B5	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 5W-50 SL/CF	XADO 10W-30 SL/CF	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	XADO 15W-40 SL/CI-4	Note	Filling capacity, L	XADO 75W-80GL 4	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO 85W-140 GL 5 LSD	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Green 11
FORD C-MAX																																									
1.6 16V	HWDA	2007-	4,4			○	●	○									2,3		●																			●	5	●	
1.8 16V	CSDA/CSDB	2007-	4,9			○	●	○									1,9		●																			●	6,5	●	
2.0 16V	DURATEC-HE	2007-	4,7			○	●	○									1,9		●					6,7		●											●	6,5	●	
1.6 TDCI 66/74 KW	HHDA	2007-	4,6			○	●	○									1,9		●																			●	7,3	●	
1.6 TDCI 80KW	G8DB	2007-	4,6			○	●	○									1,9		●																			●	7,3	●	
1.8 TDCI	BHPA	2007-08	6,7			○	●	○									1,9		●																			●	9	●	
2.0 TDCI	G6DA (DW10)	2007-	6			○	●	○									1,9		●																			●	8,4	●	
FORD COUGAR																																									
2.0I 16V	ZETEC E	1998-02	4,75	○		●	○	○									2,6				●	○															●	○		6,6	●	
2.5I 24V	DURATEC	1998-02	6	○		●	○	○									2,6				●	○		9,6		●	○									●	○		9,7	●	
FORD ESCORT																																									
1.3I	HCS/ENDURA-E,J..	1994-98	3,8			○			○	○	○		●	○	○		2,8-3,1	●					a	3,6		●	○									0,8		●		7,1	●	
1.4	PTE, F..	1994-98	3,8			○			○	○	○		●	○	○		2,8-3,1	●					a	3,6		●	○									0,8		●		7,6	●	
1.6I 16V	ZETEC	1993-98	4,75			○		●	○				○	○			2,8-3,1	○	●																	0,8		●		7	●	
1.6I 16V	ZETEC	1998-01	4,75			○	●										2,8-3,1	○	●																	0,8		●		7	●	
1.8I 16V	ZETEC	1992-96	4,75			○		●	○				○	○			2,8-3,1	●					a													0,8		●		7,5	●	
1.8I 16V	ZETEC	1996-98	4,75			○		●	○				○	○			2,8-3,1	○	●																	0,8		●		7,5	●	
1.8I 16V	ZETEC	1998-01	4,75			○	●										2,8-3,1	○	●																	0,8		●		7,5	●	
1.8 XR3I	ZETEC, R..	1992-96	4,75			○		●	○				○	○			2,6				●															0,8		●		7	●	
RS 2000I	N7A (DOHC)	1992-96	4,75			○			○	○	○		●	○	○		2,6				●															0,8		●		8	●	
RS 2000I 4X4	N7A (DOHC)	1992-96	4,75			○			○	○	○		●	○	○		2,6				●		b					1		●		c	0,8		●		8	●	
RS COSWORTH 4X4	DOHC, N5F	1992-96	3,9					●	○	○	○						1,2				●	○	d					1/1		●		e	0,8		●		7,5	●	
1.8 DIESEL	RT (OHC)	1988-98	5					●	○	○			○	○	○		2,8-3,1	○	●																	0,8		●		9,3	●	
1.8 TURBO DIESEL	RF	1993-99	5,5					●	○				○	○	○		2,8-3,1	○	●																	0,8		●		9,3	●	

Notes:

a - manual transmission: IB5 - 2,8 L XADO 75W-90 GL 3/4/5, MTX 75 - 2,6 L XADO ATF III/IV/V;

b - transfer case: 0,3 L XADO 75W-80 GL 4;

c - rear differential.

d - transfer case: 0,5 L XADO ATF III/IV/V;

e - differential: front/rear.

Engine type	Engine	Year of manufac-ture	Engine type															Transmission																		Steering booster				Cooling system		
																		Gear box											Differential													
																		Manual transmission							Automatic transmission																	
			Filling capacity, L	XADO 0W-30 SL/CF	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 A5/B5	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 5W-50 SL/CF	XADO 10W-30 SL/CF	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	XADO 15W-40 SL/CI-4	Note	Filling capacity, L	XADO 75W-80GL 4	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO 85W-140 GL 5 LSD	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Green 11
FORD FIESTA																																									
1.1I CLASSIC	HCS, G..	1996-97	3,8			○		●	○			○	○	○			2,8		●																				7,1	●	
1.25 16V	ZETEC-SE, D..	1999-01	3,5	○		●	○										2,8		●				3,5			●										●	○		7,5	●	
1.25 16V	STJA, SNJA	2008-	4,1				●	○									2,8		●																				5,5	●	
1.3I	ENDURA E, J..	1996-01	4,1	○		●	○										2,8		●																		●			7,1	●	
1.3I CLASSIC	HCS, J..	1996-97	3,8			○		●	○	○			○	○			2,8		●																					7,1	●	
1.3	BAJA-A9JA	2002-08	4,3			○	●										2,8		●																		●			5	●	
1.4 16V	ZETEC-SE, F..	1996-01	4			●	○										2,8		●																		●			5	●	
1.4 16V	FXJA	2002-08	4,1			○	●										2,8		●																		●			5	●	
1.4 16V	SPJA	2008-	4,1			●	○	○									2,8		●								a												5,5	●	
1.6 16V	ZETEC, SE	1999-01	4,8			○	●										2,8		●																		●			5	●	
1.6 16V	FYJA	2002-08	4,45			○	●										2,8		●																		●			5	●	
1.6 16V TI-VCT	HXJA	2008-	4,45				●	○									2,8		●																					5,5	●	
2.0 16V ST	DURATEC-HE	2005-08	5			○	●	○									2,8		●																		●			4	●	
1.4 TDCI	DURATORQ F6JA	2002-08	4,2			○	●	○									2,8		●																		●			5,5	●	
1.4 TDCI	F6JD	2008-	4,2			○	●	○									2,8		●																					5,5	●	
1.6 TDCI	DURATORQ-TDCI	2005-08	4,2			○	●	○									2,8		●																		●			6	●	
1.6 TDCI	HHJD	2008-	4,25			○	●	○									2,8		●																					5,5	●	
1.8 D CLASSIC	R..	1996-97	5,4					●	○				○	○	○		2,8		●																					9,3	●	
1.8 D	ENDURA DE, R..	1996-01	6			○	●	○									2,8		●																		●			9,3	●	

Notes:

a - see the Operation manual.

FORD FOCUS																																									
1.4I 16V	ZETEC-SE	1998-04	4			●	○	○	○								2,8		●																				0,8	●			5,5	●	
1.4 16V	ASDA/ASDB	2004-	4,1				●	○									2,3		●																						●	5,5	●	
1.6I 16V	ZETEC-SE	1998-04	4,75			●	○	○	○								2,8		●					6,7		●											0,8	●			5	●	
1.6 16V (74 KW)	DURATEC-16V	2004-	4,45				●	○									2,3		●					6,7		●														●	6	●	
1.6 16V (84 KW)	DURATEC-16V TI-VCT	2004-08	4,45				●	○									2,3		●																						●	6	●	
1.8I 16V	ZETEC-SE	1998-04	4,75			●	○	○	○								2,8		●					6,7		●											0,8	●			5,8	●	
1.8 16V	QQDB	2005-08	4,7				●	○									2,3		●																						●	6,5	●	
2.0I 16V	ZETEC E	1998-04	4,75			●	○	○	○								2,6		●																			0,8	●			5,8	●	
2.0 16V	DURATEC-HE	2004-	4,7				●	○									1,9		●																						●	6,3	●	
2.0 16V TURBO RS	DURATEC RS	2002-05	5				●	○									1,9		●																						●	6	●	

Engine type	Engine	Year of manufac-ture	Engine type															Transmission																		Steering booster				Cooling system		
																		Gear box											Differential					Steering booster				Cooling system		
																		Manual transmission							Automatic transmission																
			Filling capacity, L	XADO 0W-30 SL/CF	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 A5/B5	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 5W-50 SL/CF	XADO 10W-30 SL/CF	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	XADO 15W-40 SL/CI-4	Note	Filling capacity, L	XADO 75W-80GL 4	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO 85W-140 GL 5 LSD	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Green 11
2.5 20V TURBO ST	2.5 20V TURBO ST	2005-	6,7				●	○									2	○	●																		●	7,1	●	
1.6 TDCI (66 KW)	DURATORQ-TDCI	2004-08	4,2				●	○									1,9		●					6,7-8,4				a									●	7,3	●	
1.6 TDCI (74 KW)	HHDA	2008-	4,6				●	○									1,9		●																		●	7	●	
1.6 TDCI (81 KW)	DURATORQ-TDCI	2004-08	4,2				●	○									1,9		●					6,7-8,4				a									●	7,3	●	
1.8 TURBO DI	ENDURA DI	1998-04	6,2				●	○									2,6		●															0,8	●			6,5	●	
1.8 TDCI	F9DA	2000-04	6,2				●	○									2,6		●															0,8	●			6,5	●	
1.8 TDCI	BHPA	2005-08	6,7				●										1,9		●																		●	9	●	
2.0 TDCI	DURATORQ-TDCI	2004-	6				●	○									1,8		●					6,7-8,4				a									●	8,4	●	

Notes:

a - see the Operation manual.

FORD FOCUS C-MAX																																								
1.6 16V	HWDA	2003-07	4,35				●	○									2,3		●																		●	5,5	●	
1.8 16V	CSDA/CSDB	2003-07	5				●	○									1,9		●					8,9				a									●	6,5	●	
2.0 16V	DURATEC-HE	2004-07	4,7				●	○									1,9		●					6,7		●											●	8,4	●	
1.6 TDCI 66KW	HHDA	2005-07	4,6				●	○									1,9		●																		●	7	●	
1.6 TDCI,-DPF 80KW	G8DA	2003-07	4,6				●	○									1,9		●					8,9				a									●	7	●	
1.8 TDCI	BHPA	2005-07	6,7				●	○									1,9		●																		●	9	●	
2.0 TDCI	G6DA (DW10)	2003-07	6				●	○									1,8		●																		●	7	●	

Notes:

a - see the Operation manual.

FORD FUSION																																								
1.4 16V	FXJA/FXJB	2002-	4,45			●	○	○									2,3		●																	●			5	●	
1.6 16V	FYJA	2002-	4,75			●	○	○									2,3		●					5,8	●											●			5	●	
1.4 TDCI	F6JA/F6JB/F6JC	2002-08	4,6				●	○									2,3		●																	●			5,5	●	
1.6 TDCI	DURATORQ-TDCI	2005-08	4,2				●	○									2,3		●																	●			6	●	

FORD GALAXY																																								
2.0I	DOHC, NSE	1995-06	4,5				○	●					○	○			2				●			3,5		●		a	0,8	●			b				●	8,2-11	●	
2.0 16V	DURATEC-HE	2006-	5				○	●					○	○			1,9		●																		●	6,2	●	
2.3I	Y5B	1990-00	4,3					●					○	○			2				●			3,5	●			a	0,8	●			b				●	8,6-11,4	●	
2.3I	DOHC 16V	2000-06	4,3				○	●									2,3		●					3,5	●			a	0,8	●			b				●	8,6-12,3	●	
2.3 16V	SEBA (DURATEC HE)	2007-	5					●																7	●												●	6,2	●	
2.5 20V TURBO	HYDA	2006-	6,7				○	●					○	○			1,8	○	●																		●	7,1	●	
2.8I VR6, 4X4	AAA	1995-00	6					●					○	○	○		2				●		c	3,5	●			a	1/0,8	●			b,d				●	9-11,7	●	

Engine type	Engine	Year of manufac-ture	Engine type															Transmission																		Steering booster				Cooling system		
																		Gear box											Differential													
																		Manual transmission							Automatic transmission																	
			Filling capacity, L	XADO 0W-30 SL/CF	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 A5/B5	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 5W-50 SL/CF	XADO 10W-30 SL/CF	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	XADO 15W-40 SL/CI-4	Note	Filling capacity, L	XADO 75W-80GL 4	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO 85W-140 GL 5 LSD	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Green 11
2.8I CD V6	CD-V6-24V	2000-06	6					●									2,5	○	●					7,5	○	●												●	9,4-12,2	●	
1.8 TDCI	FFWA, QYWA	2006	6,7				●	○									2	○	●																		●	8	●	
1.9 TDI (66 KW)	1Z, AHU	1995-00	4,8					●					○	○	○		2				●																●	9,2	●	
1.9 TDI (66 KW)	ANU	2000-06	5,2				○	●									2,5	○	●																		●	9,2	●	
1.9 TDI (81 KW)	AFN	1997-00	4,8					●					○	○	○		2				●																●	9,2	●	
1.9 TDI (85 KW)	AUY	2000-06	5,2				○	●									2,5	○	●					7,5		●												●	7,2-10	●	
1.9 TDI (96 KW)	ASZ	2000-06	4,8				○	●									2,5	○	●																		●	7,2-10	●	
2.0 TDCI (96KW)	AZBA	2007-08	6,1				○	●																7	●												●	8,1	●	
2.0 TDCI (103 KW)	DURATORQ	2006-	6				●	○									1,9	○	●					7	●												●	8,1	●	
2.2 TDCI (129 KW)	Q4BA (DW12)	2008-	6,5				●	○									2	○	●																		●	8,4	●	

Notes:

a - service filling capacity;

b - differential (automatic transmission);

c - transfer case: XADO 75W-90 GL 3/4/5;

d - differential: front/rear.

FORD KA																																								
1.2		1996-02	3,3				○	●					○	○			2,8		●																		●			5,5	●	
1.2	169A4000	2008-	2,8				○	●									2,8		●																		●			5,25	●	
1.3 (37 KW, ENDURA-E)	ENDURA E, J..	1996-	3,8	○		●	○	○									2,8		●																		●			5,25	●	
1.3 (44 KW, ENDURA-E)	ENDURA E, J..	1996-	3,8	○		●	○	○									2,8		●																		●			5,25	●	
1.3 (44 KW, DURATEC)	BAA (DURATEC)	1996-	4,3	○		●	○	○									2,8		●																		●			5,25	●	
1.3 (51 KW, DURATEC)	A9A/A9B (DURATEC)	2001-	4,3	○		●	○	○									2,8		●																		●			5,25	●	
1.6	CDB / CDC	2002-	4,3				●	○									2,8		●																		●			5,25	●	
STREET / SPORT 1.6	CDB / CDC	2002-	4,3	○		○	●	○	○	○							2,8		●																		●			5,25	●	
1.3 Duratorq TDCi	169A1000	2008-	2,8				●	○									1,7		●																		●			6,3	●	

FORD KUGA																																								
2.5 TURBO AWD	HYDB	2008-	5,8			○	●	○															a,b	7,7	●						●		c				●		●	
2.0 TDCI FWD	G6DG (DW10)	2009	5,5			○	●	○									1,8		●																				●		●	
2.0 TDCI AWD	G6DG (DW10)	2008-	5,5			○	●	○									1,8		●				b							●		c					●		●	

Notes:

a - see the Operation manual.

b - transfer case, see the Operation manual;

c - rear differential.

Engine type	Engine	Year of manufac-ture	Engine type															Transmission																		Steering booster				Cooling system		
																		Gear box											Differential					Steering booster				Cooling system		
																		Manual transmission							Automatic transmission																
			Filling capacity, L	XADO 0W-30 SL/CF	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 A5/B5	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 5W-50 SL/CF	XADO 10W-30 SL/CF	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	XADO 15W-40 SL/CI-4	Note	Filling capacity, L	XADO 75W-80GL 4	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO 85W-140 GL 5 LSD	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Green 11
FORD MAVERICK / ESCAPE																																								
2.0 16V	ZETEC E	2000-03	4,3			○	●	○									2,2-2,7		●				a,b						1,4	○	●		c	1,9	●	○		6,7	●	○
2.3 16V	DURATEC-HE	2004-07	4,8			○	●	○									2,2-2,7		●				a,b	9,5		●			-/1,4	○	●		d	1,9	●			7,2	●	
2.4I 12V	OHC, KA24 NISSAN	1993-99	4,7			○		●	○	○			○	○			3,5		●	○			e						1,3/2,8		●		d		●			7	●	
3.0 V6	ZETEC	2000-03	5,7			○	●	○									2,2-2,7		●				a,b						1,4		●		c	1,9	●	○		10	●	○
3.0 V6	ZETEC	2003-07	5,7			○	●	○									2,2-2,7		●				b,f	9,5		●			-/1,4	○	●		d	1,9	●			10	●	○
2.7 TD	TD 27 NISSAN	1993-99	7,9				○	●	○	○		○	○	○	○		3,5		●	○			e						1,3/2,8	○	●		d		●			10	●	

Notes:

a - transfer case: XADO 80W-90 GL 3/4/5, XADO 75W-90 GL 3/4/5;

b - power takeoff: XADO 80W-90 GL 3/4/5;

c - rear differential ;

d - differential: front/rear;

e - transfer case: 2,3 L XADO ATF III/IV/V.

f - transfer case, see the Operation manual.

FORD MONDEO																																								
1.6I 16V	ZETEC, L..	1993-96	4,8			○	○	●	○	○			○	○			2,6		○		●																	7,1	●	
1.6I 16V	ZETEC E	1996-01	4,8			○	○	●	○	○							2,6		○		●																	7,1	●	
1.6 16V (81 KW)	RHBA	2007-	5,1				●										2,3		●																			6,2	●	
1.6 16V (92 KW)	PNBA	2007-	5,1				●	○									2,3		●																			6,2	●	
1.8I 16V	ZETEC, R..	1993-96	4,8			○	○	●	○	○			○	○			2,6				●			7,1		●	○											7,1	●	
1.8I 16V 4X4	ZETEC, R..	1993-96	4,8			○	○	●	○	○							2,4				●		a						1		●		b		●			6,6	●	
1.8I 16V	ZETEC E	1996-01	4,8			○	●	○	○	○							2,6		●																●			6,6	●	
1.8I 16V (81 KW)	DURATEC-HE CGBA	2001-07	4,7			○	●	○									1,9		●					7,5		●								1,8	●			8,1	●	
1.8I 16V (92 KW)	DURATEC-HE CHBA	2001-07	4,7			○	●	○									1,9		●					7,5		●								1,8	●			8,1	●	
1.8I SCI	DURATEC-SCI CFBA	2006-07	4,7			○	●	○									1,9		●																●			8,3	●	
2.0	DURATEC-HE CJBA	2001-07	4,7			○	●	○									1,9		●					7,5		●								1,8	●			8,3	●	
2.0I 16V	ZETEC, N..	1993-96	4,8			○	○	●					○	○			2,6				●			7,2		●									●			7,1	●	
2.0I 16V	ZETEC E	1996-01	4,8			○	○	●									2,6				●			8,5		●									●			7,1	●	
2.0I 16V 4X4	ZETEC, N..	1993-96	4,8			○	●	○									2,4				●		a						1		●		b		●			6,6	●	
2.0 16V	AOBA (DURATEC HE)	2007-	5				●										1,9		●																			6,2	●	
2.3 16V	SEBA (DURATEC HE)	2007-	5				●																	7	●													6,2	●	
2.5I 24V V6	DURATEC-VE, S..	1994-96	6			○	○	●	○	○			○	○			2,6		○		●			10		●									●			9,7	●	
2.5I 24V V6	DURATEC-VE	1996-01	6			○	○	●	○	○							2,6		○		●			9,7		●									●			9,5	●	
2.5	DURATEC-HE LCBD	2001-03	6				○	●									1,8		●					8,8		●								1,8	●			9,5	●	
2.5	DURATEC-VE	2003-07	6,2				○	●									1,8		●					8,8		●								1,8	●			9,5	●	
2.5 20V	HUBA (DURATEC ST)	2007-	6,7				●	○									2		●																			7,1	●	

Engine type	Engine	Year of manufac-ture	Engine type														Transmission																	Steering booster				Cooling system		
																	Gear box											Differential												
																	Manual transmission							Automatic transmission																
			Filling capacity, L	XADO 0W-30 SL/CF	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 A5/B5	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 5W-50 SL/CF	XADO 10W-30 SL/CF	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	XADO 15W-40 SL/CI-4	Note	Filling capacity, L	XADO 75W-80GL 4	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO 85W-140 GL 5 LSD	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Green 11
3.0 V6	REBA	2003-07	6,2				○	●									1,8		●					8,8		●									1,8	●			9,5	●	
3.0 V6 ST 220	MEBA	2002-07	6,2				○	●									1,8		●															1,8	●			9,5	●	
1.8 TD	RFM, RFN	1993-96	6,1					●	○	○			○	○	○		2,6		○		●														●			9,5	●	
1.8 TD	RFM, RFN	1996-01	6,1			○	●	○	○	○							2,6		○		●														●			9,3	●	
1.8 TDCI (74 KW)	FFBA	2007-08	6,7				●	○									1,9		●																		●	7,9	●	
1.8 TDCI (92 KW)	QYBA	2007-08	6,7				●	○									1,9		●																		●	7,9	●	
2.0 TDDI (66 KW)	D5BA	2001-07	6,2			○	●	○									1,9		●															1,8	●			10,4	●	
2.0 TDDI (85 KW)	D6BA	2001-07	6,2			○	●	○									1,9		●					7,9		●								1,8	●			10,4	●	
2.0 TDCI (85KW)	HJBC	2005-	6,2			○	●	○									1,9		●					7,9		●								1,8	●			10,4	●	
2.0 TDCI (96 KW)	FMBA/FMBB	2002-07	6,2			○	●	○									1,8		●					7,9		●								1,8	●			10,4	●	
2.0 TDCI (96 KW)	AZBA	2007-08	6,1				●	○											●					7	●												●	8,1	●	
2.0 TDCI (103 KW)	QXBA	2007-	6,1				●	○											●						●												●	8,1	●	
2.2 TDCI (114 KW)	DURATORQ-TDCI	2004-07	6,2			○	●	○									1,8		●															1,8	●			10,4	●	

Notes:
a - transfer case: oil as in the manual transmission;
b - rear differential.

FORD PUMA																																							
1.4 16V	ZETEC-SE, F..	1998-02	4	○		○	●	○									2,8		●																●			6	●	
1.6 16V	ZETEC SE L1W	1998-01	5	○		○	●	○									2,8		●																●			6	●	
1.7 16V	ZETEC-S VCT	1997-02	5,1	○		○	●	○									2,8		●																●			7,6	●	

FORD RANGER																																								
2.5 TDCI, 3.0 TDCI	WL	2006-	8,2			●		○	○	○			○				2,8		●				a,b	9,9		●			1,8-2/1,3-1,5		●		c	1,1	●			9,4	●	

Notes:
a - Robotized transmission: DURASHIFT - 3,5 L XADO ATF III/IV/V;
b - transfer case: for transmissions/automatic transmissions - 1,9L/1,2L ATF III/IV/V;
c - differential: front/rear.

FORD S-MAX																																							
2.0 16V	DURATEC-HE	2006-	5					●					○	○			1,8-1,9		●																		●	6,2	●	
2.3 16V	SEBA (DURATEC HE)	2007-	5				●																	7	●												●	6,2	●	
2.5 20V TURBO	HYDA	2006-	6,7					●					○	○			1,8		●																		●	7,1	●	
1.8 TDCI	FFWA, QYWA	2007-	6,7				●										1,9		●																		●	8	●	
2.0 TDCI (96KW)	AZBA	2007-08	6,2				●																	7	●												●	8,1	●	
2.0 TDCI (103KW)	DURATORQ	2006-	6				●										1,8		●					7	●												●	8,2	●	
2.2 TDCI (129 KW)	Q4BA (DW12)	2008-	6,5				●										1,8		●																		●		●	

Engine type	Engine	Year of manufac-ture	Engine type															Transmission																		Steering booster				Cooling system		
																		Gear box											Differential					Steering booster				Cooling system		
																		Manual transmission							Automatic transmission																
			Filling capacity, L	XADO 0W-30 SL/CF	XADO 0W-40 SL/CF	XADO 5W-30 SM/CF	XADO 5W-30 A5/B5	XADO 5W-40 SM/CF	XADO 5W-40 SL/CF	XADO 5W-40 SL/CF City Line	XADO 5W-50 SL/CF	XADO 10W-30 SL/CF	XADO 10W-40 SL/CI-4	XADO 10W-40 SL/CF	XADO 15W-40 SL/CI-4	Note	Filling capacity, L	XADO 75W-80GL 4	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO ATF VI	XADO ATF III/IV/V	XADO ATF III	Note	Filling capacity, L	XADO 75W-90 GL 3/4/5	XADO 80W-90 GL 3/4/5	XADO 85W-140 GL 5 LSD	Note	Filling capacity, L	XADO ATF III/IV/V	XADO ATF III	XADO CHF	Filling capacity, L	XADO Antifreeze Red 12+	XADO Antifreeze Green 11
FORD TOURNEO CONNECT																																								
1.8	EYPA	2002-07	4,8			○		●						○	○			1,9		●																	●			6,5	●	
1.8 TDCI	HCPA, RWPA	2002-	5			○	●											1,9		●																	●			7	●	